

Navigation

- [Welcome to](#)
- [Helion Interactive Documentation](#)

Welcome to

Helion Interactive Documentation and Guides

Guides

Hardware

[Hardware](#)

Getting Started

[Installation](#)

[First Start](#)

[Licence Activation](#)

[Manual Mode Installation](#)

Camera Setup

[Video Guide to Camera Setup](#)

[Camera Parts and Assembly](#)

[Connecting Camera to
LATRAS Hub](#)

[Selecting Detection Area in
LATRAS Hub](#)

[Laser Detection Activation](#)

Products

Latras Hub

[General Overview](#)

[Settings](#)

Range 1

[About Range 1](#)

[Settings](#)

[Scenarios](#)

[Analysis](#)

[Difficulties](#)

[Scoreboard](#)

[Penalties](#)

[Calibration](#)

Custom Scenarios

[Setup](#)

[Custom Targets](#)

[Precision Targets](#)

Troubleshooting

[Troubleshooting](#)

Helion Interactive Documentation

Note that this documentation is work in progress

Getting Started

All tutorials [here](#)

Video tutorials

1. [Installation](#)
2. [Simulator setup](#)

Prerequisites

- [Minimal hardware requirements](#)

Installation

- [Installation](#)
- [First start](#)
- [License activation](#)
- [Manual module installation](#)

Simulator Setup

- [Camera Assembly](#)
- [Connecting camera](#)
- [Detection Area](#)
- [Laser Detection](#)

Troubleshooting

All troubleshooting can be found [here](#)

- [Camera is not in focus](#)
- [Inconsistent laser detection](#)
- [No laser detection](#)
- [Invalid rapid shooting sounds](#)
- [Hits are drifting to the edges](#)
- [I get double shots](#)