


General

The upper toolbar controls the general settings and main functions of the LATRAS Hub



My Account - general information about product owner, registration, licence keys, and activated products.

Settings - general settings of the system, audio, shooting modes, and advanced settings of laser detection.

Update - use for automatic update of the LATRAS Hub (when an update is available)

Start - starts a camera

OTC - Object-To-Target mode, leads through definition of target areas and their properties.

Custom Drills - define any Custom Drill or Precision Shooting range with the help of this mode.

Plugin - information about existing Plug-ins, activation of new Plug-ins.

PI Mode ON/OFF - indicates if any Plug-ins run. When eg. Range1 is on, PI Mode resets to ON.

Exit - exits the LATRAS Hub

Left sided toolbar controls camera and laser functions.

Revision #7

Created 28 November 2025 10:01:49 by Editor

Updated 28 November 2025 12:06:38 by Editor