
# General

> **The upper toolbar controls the general settings and main functions of the LATRAS Hub**




My Account - general information about product owner, registration, licence keys, and activated products.

Settings - general settings of the system, audio, shooting modes, and advanced settings of laser detection.

Update -  use for automatic update of the LATRAS Hub (when an udate is available)

Start - starts a camera

OTC - Object-To-Target mode, leads through definition of target areas and their properties.

Custom Drills - define any Custom Drill or Precision Shooting range with the help of this mode.

Plugin - information about existing Plug-ins, activation of new Plug-ins.

PI Mode ON/OFF - indicates if any Plug-ins run. When eg. Range1 is on, PI Mode resets to ON.

Exit - exits the LATRAS Hub

> **Left sided toolbar controls camera and laser functions.**

Go to **Next page**

Revision #8
Created 2025-11-28 10:01:49 UTC by Editor
Updated 2026-06-19 06:02:21 UTC by Editor