Navigation

- Welcome to
- Helion Interactive Documentation

Welcome to

Helion Interactive Documentation and Guides

Guides

Hardware

Hardware

Getting Started

Installation

First Start

Licence Activation

Manual Mode Installation

Camera Setup

Video Guide to Camera Setup

Camera Parts and Assembly

Connecting Camera to LATRAS Hub

Selecting Detection Area in LATRAS Hub

Laser Detection Activation

Products

Latras Hub

General Overview

Settings

Range 1

About Range 1

Settings

Scenarios

Analysis

Difficulties

Scoreboard

Penalties

Calibration

Custom Scenarios

Setup

Custom Targets

Precision Targets

Troubleshooting

Troubleshooting

Helion Interactive Documentation

> Note that this documentation is work in progress

Getting Started

All tutorials here
Video tutorials

1. Installation
2. Simulator setup

Prerequisites

- Minimal hardware requirements

Installation

- Installation
- First start
- License activation
- Manual module installation

Simulator Setup

- Camera Assembly
- Connecting camera
- Detection Area
- Laser Detection

Troubleshooting

All troubleshooting can be found here

- Camera is not in focus
- Inconsistent laser detection
- No laser detection
- Invalid rapid shooting sounds
- Hits are drifting to the edges
- I get double shots